NEW FEATURES

■DOOR LOCK CONTROL SYSTEM

1. General

The key-linked lock and unlock function is set up as follows:


○: Available —: Not available

Function	Outline	Equipment	
		Models without Entry and Start System	Models with Entry and Start System
Key-linked Lock and Unlock	This function, linked with the driver door key cylinder, can lock or unlock all the doors when a lock or unlock operation is effected.	—*	○

*: When the ignition key is inserted into the driver door key cylinder, only the driver door can be locked or unlocked when the lock or unlock operation is performed.

2. System Diagram

▶ Models without Entry and Start System ◀



*: Models with double locking system