


TOYOTA RAV4 (EM01NAE)




Engine Control (2AD-FHV, 2AD-FTV) (From Dec. 2008 Production)


* 3 : Except 2AD-FTV w/o DPF



Engine Control (2AD-FHV, 2AD-FTV) (From Dec. 2008 Production)



* 1 : w/ Entry & Start System
* 3 : Except 2AD-FTV w/o DPF



17

(A) — W
 (B) — W
 (C) — B
 (A/T)

18

19


20

W — (A)


W — (B)

B — (C)


(A/T)



ECT and A/T Indicator (2AD-FHV)



ECT and A/T Indicator (2AD-FHV)



TOYOTA RAV4 (EM01NAE)