



[Instrument Panel] (LHD)

- * 1:w/ Entry & Start System
- * 2:w/o Entry & Start System
- * 3:Refer to the Service Bulletin for the installation position of the parts.



(RHD)



- * 1:w/ Entry & Start System
- * 2:w/o Entry & Start System
- * 3:Refer to the Service Bulletin for the installation position of the parts.