


① : Engine Room R/B Assembly	Front Fender Apron LH
○ : Engine Room J/B Assembly	



① : Engine Room R/B Assembly


○ : Engine Room J/B Assembly

Front Fender Apron LH

(Before Oct. 2015 Production Except Korea)


Unit A

Top View



Unit A


Back View



① : Engine Room R/B Assembly	Front Fender Apron LH
○ : Engine Room J/B Assembly	


(Before Oct. 2015 Production Korea)

Unit A



Unit A

Back View




① : Engine Room R/B Assembly	Front Fender Apron LH
○ : Engine Room J/B Assembly	

(From Oct. 2015 Production 2WW)

Unit A


Top View

- * 1:50A FUEL HTR
- * 2:50A EFI MAIN
- * 3:30A ABS NO.2
- * 4:50A ABS NO.1
- * 5:40A BBC
- * 6:50A H-LP-MAIN
- * 7:80A GLOW
- * 8:80A EPS



Unit A

Back View



① : Engine Room R/B Assembly


○ : Engine Room J/B Assembly

Front Fender Apron LH

(From Oct. 2015 Production Except 2WW)

Unit A

Top View



Unit A

Back View

