


Position of Parts in Body (LHD)



Position of Parts in Body (LHD)
























I1 Front No. 1 Speaker Assembly RH
I2 Front Power Window Regulator Motor Assembly RH
I4 Power Window Regulator Switch Assembly
I6 Front Door Outside Handle Assembly RH
I8 Outer Rear View Mirror Assembly RH
I10 Front Door Lock with Motor Assembly RH
I11 Door Control Switch Assembly RH
I13 Door Side Airbag Sensor RH
I14 Outer Rear View Mirror Assembly RH

J1 Front No. 1 Speaker Assembly LH
J2 Front Power Window Regulator Motor Assembly LH
J3 Front Power Window Regulator Motor Assembly LH
J5 Power Window Regulator Master Switch Assembly
J6 Front Door Outside Handle Assembly LH
J8 Outer Rear View Mirror Assembly LH
J10 Front Door Lock with Motor Assembly LH
J12 Door Side Airbag Sensor LH
J13 Seat Memory Switch LH
J14 Outer Rear View Mirror Assembly LH


K1 Rear Power Window Regulator Switch Assembly RH
K2 Rear Speaker Assembly RH
K3 Rear Power Window Regulator Motor Assembly RH
K4 Rear Door Lock with Motor Assembly RH
K5 Rear Seat Heater Switch RH

L1 Rear Power Window Regulator Switch Assembly LH
L2 Rear Speaker Assembly LH
L3 Rear Power Window Regulator Motor Assembly LH
L4 Rear Door Lock with Motor Assembly LH
L5 Rear Seat Heater Switch LH


Position of Parts in Body (LHD)




Position of Parts in Body (LHD)




90980-12550




90980-10789




90980-10935



90980-10797



90980-12226



90980-12550