



Position of Parts in Body (RHD)




N1	No. 2 Room Light Assembly
N3	Option Connector (Towing)
N5	Deceleration Sensor
N6	Front Door Courtesy Light Switch Assembly LH
N7	Front Seat Outer Belt Assembly LH
N8	Rear Door Courtesy Light Switch Assembly LH
N9	Rear Airbag Sensor LH
N10	Glass Breakage Sensor LH (Rear Door Quarter Window Glass LH)
N11	Rear Speed Sensor LH
N12	Curtain Shield Airbag Assembly LH
N13	Rear Combination Light Assembly LH
N16	Tilt Sensor (Deceleration Sensor)
N18	Noise Filter (Radio Setting Condenser)
N19	Fuel Pump Control ECU Assembly
N22	No. 31 Junction Connector
N23	No. 32 Junction Connector
N24	No. 33 Junction Connector
N27	No. 3 CAN Junction Connector
N28	No. 3 CAN Junction Connector
N29	No. 3 CAN Junction Connector
N30	No. 4 CAN Junction Connector
N31	No. 1 CAN Junction Terminal
N32	No. 5 CAN Junction Connector
N33	No. 1 Speaker with Box Assembly
N34	Rear Cross Traffic Alert Buzzer (Blind Spot Monitor Buzzer)
N36	No. 10 CAN Junction Connector
N37	Door Control Battery
N38	No. 33 Junction Connector
N39	No. 5 CAN Junction Connector


Position of Parts in Body (RHD)




90980-10860




90980-11527




90980-10845




90980-10871




90980-12452




90980-10871




90980-12699




90980-12808




90980-12936





90980-12575




90980-10795




90980-12303




90980-10957




90980-12737




90980-12737




90980-12372



90980-12827



90980-12827



90980-12827

Position of Parts in Body (RHD)

