


Position of Parts in Instrument Panel (RHD)




G103 No. 16 Junction Connector
G104 No. 17 Junction Connector
G106 No. 18 Junction Connector
G107 No. 19 Junction Connector
G108 No. 20 Junction Connector
G109 No. 21 Junction Connector
G111 No. 23 Junction Connector
G112 No. 24 Junction Connector
G113 No. 25 Junction Connector
G115 No. 27 Junction Connector
G116 No. 27 Junction Connector
G117 Diode (Brake Actuator Assembly)
G118 No. 1 CAN Junction Connector
G119 No. 1 CAN Junction Connector
G120 No. 1 CAN Junction Connector
G123 No. 1 CAN Junction Connector
G124 No. 1 CAN Junction Connector
G125 No. 1 CAN Junction Connector
G126 No. 1 CAN Junction Connector
G127 No. 1 CAN Junction Connector
G128 No. 2 CAN Junction Connector
G129 No. 2 CAN Junction Connector
G130 No. 2 CAN Junction Connector
G131 No. 2 CAN Junction Connector
G132 No. 2 CAN Junction Connector
G163 Diode (Brake Actuator Assembly)

Position of Parts in Instrument Panel (RHD)

G103


Gray



90980-12372

G104


Gray



90980-12372

G106


Blue



90980-12372

G107


Gray



90980-12372


Position of Parts in Instrument Panel (RHD)

G108
Gray




90980-12372

G109
White




90980-12372

G111
Gray



90980-12372

G112
Gray



90980-12372

Position of Parts in Instrument Panel (RHD)

