


Position of Parts in Engine Compartment (LHD)



C1	Inverter with Converter Assembly
W5	Injector Assembly No. 3
W6	Injector Assembly No. 4
X1	Knock Control Sensor (Bank 1)
Z1	Front No. 1 Ultrasonic Sensor LH
Z2	Front No. 1 Ultrasonic Sensor Center LH
Z3	Front No. 1 Ultrasonic Sensor Center RH
Z4	Front No. 1 Ultrasonic Sensor RH
Z5	Front Television Camera Assembly
Z6	Millimeter Wave Radar Sensor Assembly
q1	Cooling Fan ECU
t1	Inverter with Converter Assembly
t2	Inverter with Converter Assembly
v1	Inverter with Converter Assembly
v3	Hybrid Vehicle Transaxle Assembly
w1	Inverter with Converter Assembly
w3	Hybrid Vehicle Transaxle Assembly
z14	Cooling Fan ECU , Cooling Fan Motor
z15	Cooling Fan ECU , No. 2 Cooling Fan Motor

Position of Parts in Engine Compartment (LHD)

