



Position of Parts in Instrument Panel (LHD)




Position of Parts in Instrument Panel (LHD)

G2	Automatic Light Control Sensor
G5	Steering Lock Actuator Assembly
G8	Spiral Cable Sub-Assembly
G9	Spiral Cable Sub-Assembly
G10	Windshield Wiper Switch Assembly
G11	Windshield Wiper Switch Assembly
G12	Steering Sensor
G13	Headlight Dimmer Switch Assembly
G14	DLC3
G16	Combination Meter Assembly
G17	Combination Meter Assembly
G19	Cooler (Room Temperature Sensor) Thermistor
G20	A/C Control Assembly
G24	Power Switch
G26	Seat Heater Switch RH
G27	Seat Heater Switch LH
G28	No. 2 Power Outlet Socket Assembly
G31	Lower No. 1 Instrument Panel Airbag Assembly
G34	No. 1 Clearance Warning Buzzer
G35	Shift Lock Control ECU (Floor Shift Lever Sub-Assembly)
G36	Transmission Control Switch
G37	Parking Brake Switch Assembly
G39	Outer Mirror Switch Assembly
G40	No. 1 Power Outlet Socket Assembly
G43	Telltale Light Assembly
G44	ID Code Box (Immobiliser Code ECU)
G45	No. 1 Indoor Electrical Key Antenna Assembly
G46	Radio Receiver Assembly
G47	Radio Receiver Assembly
G48	Radio Receiver Assembly
G141	Radio & Display Receiver Assembly
G142	Radio & Display Receiver Assembly
G143	Radio & Display Receiver Assembly


Position of Parts in Instrument Panel (LHD)




90980-12056




90980-12092




90980-12370




90980-12160




90980-12358




90980-12359




90980-12366




90980-12460




90980-11978




90980-12557




90980-12767




90980-11918




90980-12551




90980-12368




90980-12135




90980-12012




90980-12498




90980-12452




90980-10825




90980-12910



90980-12954




90980-10871




90980-12554


Position of Parts in Instrument Panel (LHD)




90980-12498




90980-12554




90980-12366




90980-12795




90980-10997




90980-10996




90980-12555



90980-10997



90980-10996



90980-12555