


















Position of Parts in Instrument Panel (RHD)




G54	Blower Assembly
G59	Airbag Cut Off Switch Cylinder Sub-Assembly
G61	Windshield Wiper Switch Assembly
G62	Windshield Wiper Switch Assembly
G63	Headlight Dimmer Switch Assembly
G64	Shift Illumination (Indicator Light Wire Sub-Assembly)
G68	Headlight Leveling Switch
G71	Tire Pressure Warning Reset Switch
G73	Back Door Control Switch
G74	Lane Departure Alert Buzzer (Skid Control Buzzer Assembly)
G78	Main Body ECU
G79	Main Body ECU
G81	A/C Amplifier Assembly
G82	Certification ECU
G83	Certification ECU
G84	Certification ECU
G85	Windshield Wiper Relay Assembly
G92	Airbag Sensor Assembly
G98	No. 11 Junction Connector
G99	No. 12 Junction Connector
G101	No. 14 Junction Connector
G103	No. 16 Junction Connector
G104	No. 17 Junction Connector
G106	No. 18 Junction Connector
G107	No. 19 Junction Connector
G108	No. 20 Junction Connector
G109	No. 21 Junction Connector


Position of Parts in Instrument Panel (RHD)




Position of Parts in Instrument Panel (RHD)




90980-12444




90980-12391



90980-12372




90980-12372



90980-12372


Position of Parts in Instrument Panel (RHD)

G103
Gray




90980-12372

G104
Gray




90980-12372

G106
Blue



90980-12372


G107
Gray



90980-12372


Position of Parts in Instrument Panel (RHD)

G108
Gray



90980-12372

G109
White



90980-12372