
REAR FLOOR SIDE PANEL REAR EXTENSION (ASSY)



F29842A

With the quarter panel removed.


Symbol meaning


REMOVAL	: Remove Weld Points
INSTALLATION	: Spot Weld : Plug Weld

F29842B

REMOVAL·INSTALLATION

[LH]






F29842

INSTALLATION POINT

1 After welding, apply body sealer and undercoating to the corresponding parts. (See the paint·coating)
2 After applying the top coat, apply anti-rust agent to the internal panel portion of the closed section structural weld points.

[RH]



F29843

INSTALLATION POINT

1 After welding, apply body sealer and undercoating to the corresponding parts. (See the paint·coating)
2 After applying the top coat, apply anti-rust agent to the internal panel portion of the closed section structural weld points.