


■ LAYOUT OF MAIN COMPONENTS



08LBE10Y


Front Corner
Sensor RH
Front Corner
Sensor LH


Rear Corner
Sensor LH
Rear Corner
Sensor RH
Back Sensor LH
Back Sensor RH

08LBE38Y