POWER BACK DOOR SYSTEM

■ DESCRIPTION

The power back door system enables the back door to be opened and closed automatically by a motor in accordance with signals from the power back door opener/closer switch or the power back door button on the transmitter.
In addition, a power back door closer switch has been provided on the back door for convenience.

- The power back door system is standard equipment on the Platinum grade and optional equipment on the Limited grade.
- This system is controlled by the power back door ECU. The power back door ECU is built into the power back door drive unit.
- This system is activated when the following conditions are all met:
  - PWR DOOR OFF switch is OFF (the power back door opener has not been disabled using the switch).
  - Shift lever is in the “P” position.
  - Vehicle speed is 5 km/h (3 mph) or less.
- This system has a one-motion opener function to secure usability. This function allows the power back door to be opened from a locked state without the need to unlock it first.