

SRS AIRBAG SYSTEM

■ DESCRIPTION

- An SRS airbag system is standard equipment on all models.
- The driver and front passenger dual-stage SRS (Supplemental Restraint System) airbags supplement the seat belts to help to reduce the shocks to the heads and chests of the driver and front passenger in the event of a frontal collision.
- The SRS side airbags are used in the event of a side impact collision to help to reduce the shocks to the chests of the driver or front passenger.
- The SRS curtain shield airbags are used in the event of a side or rear side impact collision to help to reduce the shocks to the heads of the driver, front passenger, rear No. 1 seat outer passengers or rear No. 2 seat outer passengers.



08LMO042I



08LMO036Y