
STEERING PAD SWITCH

■ DESCRIPTION

- Steering pad switches are standard equipment.
- The switches used frequently are located on the steering pad for easy use.
- The steering pad switches that are provided on the steering pad may vary due to optional equipment, as indicated in the table below.

Item	Switch
Audio*1	● Volume +/– ● Seek Up/Down ● MODE
Navigation*2	Voice
Telephone*3	● Voice ● ON/OFF Hook
Air Conditioning	● TEMP Up/Down ● OFF/AUTO
Dynamic Laser Cruise Control*4	Distance Control

*1: Models with Premium Audio System
*2: Models with Navigation with AV System
*3: Models with Bluetooth Hands-free System
*4: Models with Dynamic Laser Cruise Control System



08LBE05Y

BE