

■ REAR SUSPENSION

Through the optimal allocation of components, the front suspension realizes excellent riding comfort and controllability.



Model without Air Suspension System



Model with Air Suspension System and AVS System

Service Tip

The camber and toe-in of the rear suspension can be adjusted using the adjustment cams of the lower arms. For details, see the 2008 Sequoia Repair Manual (Pub. No. RM08L0U).

