
■SRS AIRBAG SYSTEM

1. General

- Supplemental Restraint System (SRS) knee airbags are provided as standard equipment on all models. An SRS knee airbag is provided both on the driver seat and front passenger seat.
- The SRS knee airbags help restrain the lower parts of the bodies of the driver and front passenger, thus enhancing the excellent passenger protection provided by the seat belts and front airbags.




2. Airbag for Frontal Collision

General

The airbag for frontal collisions is composed of the driver and front passenger dual-stage SRS airbags and the driver and front passenger SRS knee airbags. These airbags deploy simultaneously.

System Diagram



SRS Knee Airbags

- The SRS knee airbags deploy simultaneously with the front airbags in a frontal collision. With the deployment of the SRS knee airbags, the driver's and front passenger's lower bodies are restricted, thus enhancing the excellent passenger protection provided by the seat belt and front airbags.
- The SRS knee airbag consists of an airbag door, an inflator, and a bag.

