


■ LAYOUT OF MAIN COMPONENTS





BE


PWR
DOOR
OFF
Power Back Door
Opener/Closer Switch
PWR DOOR
OFF Switch
Power Back
Door Button
HOLD
HOLD
Transmitter
Main Body ECU
(Driver Side Junction Block)
11YBE046Y