ENGINE IMMOBILISER SYSTEM

■ DESCRIPTION

The engine immobiliser system compares the ID code registered in the transponder key ECU with the ID code of the transponder chip that is embedded in the ignition key. The system unsets if these ID codes match. Thus, the transponder key ECU and the ECM communicate with each other to authorize fuel injection and ignition, enabling the engine to start.

- The engine immobiliser system is provided as standard equipment on all models.

Service Tip

When replacing the transponder key ECU or making a new ignition key, and the key's recognition code must be registered.