

■ LAYOUT OF MAIN COMPONENTS



BE


SRS Warning Light
RSCA OFF
Indicator Light
PASSENGER
AIR BAG
ON
OFF
AIRBAG ON
Indicator Light
AIRBAG OFF
Indicator Light
SRS Driver Airbag
DLC3
SRS Front Passenger Airbag
RSCA
OFF
RSCA OFF Switch
Center Airbag Sensor
Assembly

11YBE083I