CRUISE CONTROL SYSTEM

■ DESCRIPTION

When the cruise control system is set to a desired vehicle speed, the throttle valve position is adjusted automatically to maintain the vehicle speed without the driver having to depress the accelerator pedal.

- The cruise control system effects control through the Electronic Throttle Control System-intelligent (ETCS-i).
- The cruise control system is standard equipment for all models.

■ SYSTEM DIAGRAM

