HEATED & VENTILATED SEAT SYSTEM

■ DESCRIPTION

The heated & ventilated seat system has a heating function and a ventilation function, in addition to the blower units in the conventional seat ventilation system. This creates a very comfortable seat.

- The heating function and the ventilation function cannot be operated at the same time.
- For the ventilation function, only air in the cabin is used and hot or cold air is not blown.
- The air conditioning amplifier controls the ventilation function.
- The seat heater controller in each seat controls the heating functions individually.
- The heated & ventilated seat system is the standard equipment for the driver and front passenger seats of the Platinum grade.

■ SYSTEM DIAGRAM

The heated & ventilated seat system consists of the seat heater, blower unit, seat heater & ventilation volume switch, seat heater controller, and air conditioning amplifier.

