MEMORY SYSTEM

■ DESCRIPTION

The memory system can store the position of the driver seat, outside rear view mirror, and tilt & telescopic. The positions for up to 2 different drivers can be stored in the system memory and recalled.

- The memory system is standard equipment on the Platinum grade and optional equipment on the Limited grade.
- The positions for up to 2 different drivers can be saved using the memory switch.
- The driver seat ECU stores the 4 recordable adjustments of the seat (seat slide, front vertical, rear vertical and recline position) in its memory. The driver seat ECU is built into the power seat switch for the driver seat.
- The mirror ECU stores the outside rear view mirror position in its memory.
- The tilt & telescopic ECU stores the tilt & telescopic position in its memory.
- The driver seat ECU outputs a signal to each ECU to reproduce a stored position.
- The memory and recall conditions of this system are as follows:

Function	Condition
Memory	Memorizes the positions when all conditions below have been met and the button 1 or 2 is pushed while the “SET” button is pushed: ● Ignition switch is ON. ● Shift lever is in P. When the memory setting is completed, the buzzer in the power seat switch will sound for 0.5 seconds.
Recall	If the button 1 or 2 is pressed when all conditions below have been met, it recalls the positions: ● Ignition switch is ON. ● Shift lever is in P. If the button 1 or 2 is pressed when all conditions below have been met, it recalls the positions within 30 seconds: ● Ignition switch is off. ● Driver door is opened.