
STEERING PAD SWITCH

■ DESCRIPTION

- The switches used frequently are located on the steering pad for easy use.
- The steering pad switches provided on the steering pad may vary due to optional equipment, as indicated in the table below:

Item	Switch	Equipment	
		Limited Grade	Platinum Grade
Audio	● Volume +/– ● Seek Up/Down ● MODE	Standard	Standard
Air Conditioning	● TEMP Up/Down ● OFF/AUTO	Standard	Standard



11YBE061Y