
ENHANCEMENT OF PRODUCT APPEAL

■WASHER NOZZLE


1. Front Washer

Spray type washer nozzles are located under the engine hood to help ensure a tidy appearance. These nozzles can spray the windshield with an oscillating stream to optimally distribute and spread washer fluid. When washer fluid is sprayed from under the engine hood, the spray trajectory is less affected by airflow, thus maintaining a favorable spray trajectory at high speeds.



08LBO023I

: Spray area




08LBO024I

BO


2. Rear Washer

The spray type washer nozzle is located on the rear spoiler* or the high-mount stop light.

*: Models with rear spoiler



Models with Rear Spoiler 08LBO025I



Models without Rear Spoiler 08LBO026I