

■REAR SUSPENSION

Through the optimal allocation of components, the front suspension achieves excellent riding comfort and controllability.



Models without Rear Air Suspension System



Models with Rear Air Suspension System and AVS

Service Tip

The camber and toe-in of the rear suspension can be adjusted using the adjustment cams of the lower arms. For details, refer to the SEQUOIA Repair Manual (Pub. No. RM11Y0E).