
EQUIPMENT

TOYOTA Parking Assist-sensor System

- The TOYOTA parking assist-sensor system is provided as standard equipment for the Limited and Platinum grades, and is available as optional equipment for the SR5 grade.
- The TOYOTA parking assist-sensor system informs the driver of the approximate distance between the sensors and the obstacles as well as their positions by displaying them on the accessory meter and by sounding a buzzer in the accessory meter.



11YMO020I