■ FUNCTION OF MAIN COMPONENTS

Component		Function
Television Display Assembly		● Displays Blu-ray disc output images, DVD output images, adjustment screen, option screen, and diagnosis screen. ● Receives signals from remote controller. ● Outputs audio signals to the wireless headphone in the form of infrared signals.
	RSE ECU	Processes audio and visual signals from the Blu-ray disc player, or SD card slot, and outputs them.
	Blu-ray Disc Player	Outputs the audio and visual signals to the RSE ECU.
	SD Card Slot	
Remote Controller		Outputs various control signals for the RSES to the television display assembly in the form of infrared signals.
Navigation Receiver Assembly*		● Receives audio signals from the television display assembly and outputs them to the speakers. ● Turn ON/OFF the child lock function (disables operation of the RSES through the remote controller or panel buttons on the television display assembly) by the screen setting. ● Turn ON/OFF the RSES from front seat by the adjustment screen.
Steering Pad Switch LH		The MODE button changes the audio source.*

*: Models with navigation with AV system