
F RELAY LOCATIONS

⑥ : R/B No.6	Engine Compartment Left (See Page 20)



⑦ : R/B No.7	Left Instrument Panel Reinforcement (See Page 20)

