



Taillight





Taillight

: Parts Location

Code		See Page	Code		See Page	Code		See Page
B6	A	38	J37	43		P3	37	
C11		39	J38	43		R19	44	
F6	A	36	J39	43		R20	44	
F7	B	36	J41	43		R21	44	
J27		40	L2	43		R22	44	
J31	A	40	L3	43		S1	37	
J32	B	40	P2	37		S2	37	

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	31	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
1C		
1L	31	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
1P	31	Floor No.1 Wire and Driver Side J/B (Lower Finish Panel)

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
BG1	55	Back Door No.1 Wire and Floor No.1 Wire (Left Rear Quarter Panel)

: Ground Points

Code	See Page	Ground Points Location
EA	50	Front Side of the Right Fender Apron
ED	50	Front Side of the Left Fender Apron
IE	52	Left Kick Panel
BL	54	Right Rear Quarter Panel
BM	54	Left Rear Quarter Panel
BN	54	Left Side of the Back Door

