



Audio System with 6 Speaker





Audio System with 6 Speaker

: Parts Location

Code	See Page	Code	See Page	Code	See Page
C10	39	J19	40	R30	44
C13	39	J20	40	S3	A 37
F17	42	J35	A 40		B 37
F18	42	J36	B 40	S32	41
J7	A 40	R2	A 41	T8	41
J8	B 40	R3	B 41	T9	41
J11	A 40	R4	C 41		
J12	B 40	R29	44		

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1C	31	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
1H	30	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
1L	31	
2B	24	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
2C		

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA2	52	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
IM1	53	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)

: Ground Points

Code	See Page	Ground Points Location
IF	52	Instrument Panel Brace LH

