

* 5:JBL
* 6:Except JBL
T10
T9
T14
R19
R20
R15
(*6)
R10
(*5)
R17
R14
(*6)
R3
(*5)
R16
R11
Z3
R4
T20
S10
T7
Z2
R1
R2
T17
T15
S8
S32
U1
T18
S7

R 1 Radio Receiver Assembly
R 2 Radio Receiver Assembly
R 3 Radio Receiver Assembly
R 4 Rheostat
R 10 Radio Receiver Assembly
R 11 Radio Setting Condenser
R 14 Radio Receiver Assembly
R 15 Radio & Display Receiver Assembly
R 16 Radio & Display Receiver Assembly
R 17 Radio & Display Receiver Assembly
R 19 Radio & Display Receiver Assembly
R 20 Radio & Display Receiver Assembly


S 7 Shift Lock Control ECU
S 8 Spiral Cable
S 10 Stop Lamp SW
S 32 Steering Sensor

T 7 Towing Brake Controller
T 9 Transponder Key Amplifier
T 10 Transponder Key ECU
T 14 Tire Pressure Warning ECU
T 15 Tire Pressure Warning Reset SW
T 17 Traction Control SW
T 18 Traction Control SW
T 20 Turn Signal Flasher

U 1 Unlock Warning SW

Z 2 Option Connector (Trailer Socket)
Z 3 Option Connector (TVIP)


R 1
White



R 2
Blue




R 3
White




R 4
Blue



R 10
White




R 11
White




R 14
White




R 15
White




R 16
White



R 17
White



R 19
White



R 20
White




S 7
White




S 8
Black




S 10
Blue




S 32
White




T 7
White




T 9
Black




T 10
White




T 14
Black




T 15
Black




T 17
Black



T 18
Black




T 20
White



U 1
White



Z 2
White



Z 3
White

