

D73
D72
D71
D74
D59
D38
D35
D66
D34
D70
D67
D68
D63
D65
D33
D61
D58
D50
D48
D52
D54
D60
D46 (*2)
D46 (*1)
D57
D43
D36
D77
D42
* 1:4WD
* 2:2WD

D 33 Air Fuel Ratio Sensor (Bank 1 Sensor 1)
D 34 Air Fuel Ratio Sensor (Bank 2 Sensor 1)
D 35 Park/Neutral Position Switch
D 36 VVT Sensor (Bank 1)
D 38 VVT Sensor (Bank 2)
D 42 Camshaft Timing Oil Control Valve (Bank 1)
D 43 Camshaft Timing Oil Control Valve (Bank 2)
D 46 Power Steering Oil Pressure Sensor
D 48 Air Injection Control Driver (Bank 1)
D 50 Air Injection Control Driver (Bank 1)
D 52 Air Injection Control Driver (Bank 2)
D 54 Air Injection Control Driver (Bank 2)
D 57 Air Pump (Bank 2)
D 58 Air Switching Valve (Bank 1)
D 59 Air Switching Valve (Bank 2)
D 60 A/C Compressor
D 61 ACIS VSV
D 63 Automatic Transmission
D 65 Transmission Revolution Sensor (Turbine)
D 66 Transmission Revolution Sensor (Electronically Controlled Transmission)
D 67 Transfer Shift Actuator
D 68 Transfer Shift Actuator
D 70 Transfer Shift Actuator
D 71 Junction Connector
D 72 Junction Connector
D 73 Junction Connector
D 74 Engine Control Module
D 77 Oil Pressure Sender


D 33
Dark Gray



D 34
Dark Gray



D 35
Gray



D 36
Dark Gray



D 38
Dark Gray




D 42
Black




D 43
Black




D 46
Gray




D 48
Black




D 50
Black




D 52
Gray



D 54
Gray



D 57
Gray



D 58
Black




D 59
Black




D 60
Gray




D 61
Black




D 63
Gray




D 65
Black




D 66
Black




D 67
Black




D 68
Dark Gray




D 70
Black




D 71
White




D 72
White



D 73
Blue



D 74
Black



D 77
Black

