

D73
D74
D71
D66
D65
D64
D63
D70
D67
D68
D48
D72
D59
D58
D57
D50
D52
D54
D46
D45
D76
D56
D62
D60
D75
D44

D 44 Camshaft Timing Oil Control Valve (Bank 1 Exhaust Side)
D 45 Camshaft Timing Oil Control Valve (Bank 2 Exhaust Side)
D 46 Power Steering Oil Pressure Sensor
D 48 Air Injection Control Driver (Bank 1)
D 50 Air Injection Control Driver (Bank 1)
D 52 Air Injection Control Driver (Bank 2)
D 54 Air Injection Control Driver (Bank 2)
D 56 Air Pump (Bank 1)
D 57 Air Pump (Bank 2)
D 58 Air Switching Valve (Bank 1)
D 59 Air Switching Valve (Bank 2)
D 60 A/C Compressor
D 62 ACIS VSV
D 63 Automatic Transmission
D 64 Automatic Transmission
D 65 Transmission Revolution Sensor (Turbine)
D 66 Transmission Revolution Sensor (Electronically Controlled Transmission)
D 67 Transfer Shift Actuator
D 68 Transfer Shift Actuator
D 70 Transfer Shift Actuator
D 71 Junction Connector
D 72 Junction Connector
D 73 Junction Connector
D 74 Engine Control Module
D 75 Camshaft Timing Oil Control Valve (Bank 1 Intake side)
D 76 Camshaft Timing Oil Control Valve (Bank 2 Intake Side)


D 44
Black




D 45
Black




D 46
Gray




D 48
Black




D 50
Black




D 52
Gray




D 54
Gray



D 56
Gray



D 57
Gray



D 58
Black




D 59
Black




D 60
Gray




D 62
Black




D 63
Gray




D 64
Gray




D 65
Black




D 66
Black




D 67
Black




D 68
Dark Gray




D 70
Black




D 71
White




D 72
White



D 73
Blue



D 74
Black



D 75
Black



D 76
Black

