

P7
P12
Y4
Y1
Y5
Y7
T9
T4
T1
T8
Y6
Q11
Q12
Q9

P 7 Front Seat Inner Belt Switch LH
P 12 Front Side Airbag Squib Circuit LH

Q 9 Front Side Airbag Squib Circuit RH
Q 11 Occupant Detection ECU
Q 12 Front Seat Inner Belt Switch RH

T 1 Power Outlet Socket (115V)
T 4 Video Terminal
T 8 Power Outlet Socket (No.2)
T 9 Power Outlet Socket (No.3)

Y 1 Occupant Detection ECU
Y 4 Front Occupant Classification Sensor LH
Y 5 Front Occupant Classification Sensor RH
Y 6 Rear Occupant Classification Sensor LH
Y 7 Rear Occupant Classification Sensor RH

P 7
White




P 12
Yellow




Q 9
Yellow



Q 11
Black




Q 12
Gray



T 1
Black



T 4
White




T 8
White




T 9
White




Y 1
Gray




Y 4
Black



Y 5
Gray



Y 6
Gray



Y 7
Black

