


■ LAYOUT OF MAIN COMPONENTS



04E0BE124Z



04E2BE22Z


Evaporator Temperature Sensor
Air Vent Servo Motor
Evaporator
Cool Air Bypass Servo Motor
(Automatic A/C Only)
Air Inlet Outlet Servo Motor
Air Mix Servo Motor
(For Driver)
Blower Motor
Heater Core
Air Mix Servo Motor
(For Front Passenger)

04E0BE41Z