
SRS AIRBAG SYSTEM

■ DESCRIPTION


The SRS (Supplemental Restraint System) has the following equipment:

Item		Regular Cab	Double Cab	CrewMax
Frontal Collision	Driver and Front Passenger	Standard	Standard	Standard
	Seat Belt Pretensioner	Standard	Standard	Standard
Side/Side Rear Collision	Side	Standard	Standard	Standard
	RSCA (Roll Sensing Curtain Shield Airbags)	Standard	Standard	Standard
Front Passenger Occupant Classification System		Standard	Standard	Standard
Airbag Manual AUTO-OFF System		Standard	-	-

- The SRS driver and front passenger airbags are used as supplements to the seat belts to help to reduce the shocks to the head and chest of the driver or front passenger in the event of a frontal impact collision.
- The SRS side airbags are used in the event of a side impact collision to help to reduce the shocks to the chest of the driver or front passenger.
- The SRS curtain shield airbags are used in the event of a side or side rear impact collision to help to reduce the shocks to the head of the driver, front passenger, or rear outer passengers.




Regular Cab 04E0BE72Z



Double Cab

04E0BE73Z



CrewMax

04E2BE18Z