
■A.D.D. SHIFT ACTUATOR

The A.D.D. shift actuator contains the A.D.D. shift motor, limit switch and A.D.D. detection switch. It should not be disassembled.

- The limit switch has two contact point switches (DL1 and DL2). Different combinations of the two contact point switches allow detection of the A.D.D. state (disconnect or connect).



▶ Combinations of Two Contact Point Switches ◀

