THEFT DETERRENT SYSTEM

■ DESCRIPTION

The theft deterrent system can sound an alarm when somebody attempts to forcibly enter the vehicle, open the engine hood, unlock any door without the key, or when the battery terminals are removed and reconnected.

- The system consists of door lock control system parts, wireless door lock control system parts, security horn and security indicator light.
- This system is controlled by the Main Body ECU (Driver Side Junction Block).
- The warning specifications of this system are listed below.

Warning Method	Interior Light	Illuminates
	Hazard Lights	Blink
	Exterior Lights	Blink
	Vehicle Horn	Sounds a warning on a 0.4 second cycle (approx.)
	Security Horn	Sounds a warning on a 0.4 second cycle (approx.)
	Door Lock Motor	Lock
Warning Time		Approximately 60 seconds

- The theft deterrent system has the following functions and equipment:

×: Standard OP: Option -: Not Equipped

Function	Regular Cab		Double Cab			CrewMax	
	1GR-FE	2UZ-FE/ 3UR-FE	1GR-FE	2UZ-FE/3UR-FE		2UZ-FE/3UR-FE	
			SR5	SR5	Limited	SR5	Limited
Alarm	-	OP	-	OP	×	OP	×
Alarm + Glass Breakage Detection Function	-	OP	-	OP	OP	OP	OP