■ FUNCTION

The Bluetooth hands-free system has the following functions:

Function		Outline
Calling with a Bluetooth Phone	By Dial Pad	The user can call by inputting a telephone number.
	By Contacts	The user can call by using the contact data that has been transferred from the user's cellular phone. The user can register up to 2500 items in the contact list.
	By Home Screen	The user can make a call by using the widget on the home screen.
	By Call History*1	The user can call by selecting a telephone number from all call history. However, the number of the telephone numbers in the call history that the user can use is limited while driving.
	By Favorites*1	The user can call by using a registered telephone number selected from the contact list, dialed numbers or received calls.
	By Voice Recognition (Dialing by Name)*1	The user can call by saying a name registered in the contact list.
	By Voice Recognition (Dialing by Phone Number)*1	The user can call by saying a desired number.
	By Point Of Interest (POI)*2	The user can call by operating a switch when "Call" is displayed on the navigation screen.
	By Entune*3	Telephone calls can be made to destinations found through Entune.
	By Short Message Service (SMS)/Multimedia Messaging Service (MMS)/e-mail (reception screen)*1	The user can call by operating a switch when "Call" is displayed on the incoming message screen.
	By Short Message Service (SMS)/Multimedia Messaging Service (MMS)/e-mail (mail screen)*1	The user can call by operating a switch when "Call" is displayed on the mail screen.
	By Short Message Service (SMS)/Multimedia Messaging Service (MMS)/e-mail (text messages)	The user can call by operating a switch when telephone numbers are displayed in blue in the text message.
Receiving a Call using a Bluetooth Phone*1		When a call is received, the incoming call screen is displayed with a sound.
Talking on a Bluetooth Phone*1		While the user is talking on the phone, the talking screen is displayed.

(Continued)

Function		Outline
Changing Bluetooth Phone Settings	Favorites Registration	The user can register a desired telephone number from the contact list, dialed numbers or received calls. Up to 15 favorite telephone numbers can be registered.
	Volume Settings	The user can set the volume. The user can change the incoming call volume and volume when an e-mail arrives on the setting screen, and change the incoming and outgoing call volume on the screen shown while the user is talking on the phone.
	Contact Settings	Transferring a telephone number: The user can transfer telephone numbers from the Bluetooth phone to the system. Up to 2500 data items (up to 4 numbers and e-mail addresses per entry) can be registered in the contact list.
		Automatically transferring a telephone number: When a PBAP compatible phone is connected, the phonebook data of the phone can be automatically transferred.
		Registering phone numbers: The user can register phone numbers in the contact list.*4
		Adding data to the contact list: The user can add data to the contact list.*4
		Editing data: The user can edit the registered data.*4
		Deleting data: The user can delete the data.*4
		Deleting all the phone data: The user can delete all the phone data.*4
		Deleting the call history data: The user can delete the call history data all at once.*4
	Screen Settings	Receiving call display: The user can select the receiving call display.
		Contact data and call history data transfer condition: The user can select whether a message is displayed or not while transferring contact data and call history data.
		The Bluetooth connection status at startup: When the ignition switch is turned ACC or ON and the Bluetooth is automatically connected, the connection check will be displayed.
		Initializing the settings: The user can initialize the settings.

(Continued)

Function		Outline
Registering and Selecting a Bluetooth Phone	Bluetooth Phone Registration	In order to use the hands-free function of a Bluetooth phone, it is necessary to register it in the radio receiver assembly. Once a phone is registered, the hands-free function connects automatically. The user can register up to 5 Bluetooth phones.*5
	Bluetooth Phone Selection*1	When 2 or more registered Bluetooth phones are in the cabin, it is necessary to select which phone to use to prevent the lines from being crossed. Only the selected phone is available for use as a hands-free phone. The phone registered last is automatically selected.
	Bluetooth Information Confirmation and Editing	The user can set, change and initialize the information of the Bluetooth phone displayed on the screen.
	Deleting a Bluetooth Phone	The user can delete a registered Bluetooth phone from the audio head unit.
Bluetooth Phone Message*6	Checking Message	Transmits the messages (Short Message Service (SMS)/Multimedia Messaging Service (MMS)/e-mail) received on the Bluetooth phone to the audio head unit. The following functions are available for the transmitted messages. – Display of the message text. – Reading out of the message.*1 – Calling a Short Message Service*1 (SMS)/Multimedia Messaging Service (MMS)/e-mail message sender's phone number.
	Reply Message*1	Replies to a message (Short Message Service (SMS)/Multimedia Messaging Service (MMS)/e-mail) received on the Bluetooth phone.
	Editing Reply Message	Edits the reply.
	Displaying Mail List*1	Displays the list of received messages (Short Message Service (SMS)/Multimedia Messaging Service (MMS)/e-mail). However, the number of the received messages in the list that the user can view is limited while driving.

*1: Can be operated while driving.
*2: Models with display and navigation module display
*3: Except models with base grade radio and display receiver assembly
*4: PBAP non-compatible phone, or PBAP compatible phone with the automatic telephone number transfer function set to off
*5: The maximum number of Bluetooth devices that can be registered (including Bluetooth phones and Bluetooth audio players).
*6: Depending on the phone connected, some message services (checking or replying to messages, or displaying mail list) are not available.