
■CONSTRUCTION AND OPERATION

1. Ultrasonic Sensor

▶ Ultrasonic Sensor ◀




’14 Model **’13 Model**

24WBE027Y

2. Multi-information Display


- The items displayed by the multi-information display are the location of the obstacle and the approximate distance between the vehicle and the obstacle, warning messages relating to sensor malfunction, sensor freezing, or presence of dirt on the sensor. When any warning messages are displayed the buzzer sounds.
- The number of lines indicates the distance to an obstacle. As the distance to an obstacle decreases, the number of lines also decreases to indicate the change in distance. Yellow lines indicate a long or medium-range distance, and red lines indicate a close-range distance.



▶ Warning Message ◀



Ultrasonic Sensor Malfunction Warning



Ultrasonic Sensor Freeze/Contamination Warning