

Front Wiper and Washer (w/ Intermittent Wiper)
Front Wiper and Washer (w/o Intermittent Wiper)
1
2
3
4
J12(A), J13(B)
Windshield Wiper Switch
Front Wiper Switch
MIST (*2)
Mist (*1)
OFF (*2)
Off (*1)
INT (*2)
Intermittent (*1)
LO (*2)
Low (*1)
HI (*2)
High (*1)
B1
INT2
INT1
+S
+1
+2
+B
Front
Washer
Switch
Off
On
EW
W
Wiper Relay
(IG)
30A
WIPER
20A
WSH
A22
Washer Motor
A21
Windshield Wiper Motor
A44
Junction
Connector
J60
Junction
Connector
AJ11
A2
J1
WF
EW
W–B
GR
LG
BR
G
Y
W
B
R
* 1 : Canada, South America
* 2 : Except *1