

Frame Wire
Engine No.6 Wire
D3
D2
Sensor Wire
D1
Engine Wire
Engine No.7 Wire
Skid Control Sensor Wire
A4
A3
Skid Control Sensor Wire
A2
A1
Engine Room Main No.3 Wire
Differential Wire
Engine No.2 Wire
Engine Room Main Wire
Engine Room Main No.4 Wire