



D74
D71
D65
D59
D66
D62
D58
D70
D68
D67
D63
D64
D48
D50
D52
D54
D60
D73
D72
D90
D46
D76
D89
D75

D 46 Power Steering Oil Pressure Sensor
D 48 Air Injection Control Driver (Bank 1)
D 50 Air Injection Control Driver (Bank 1)
D 52 Air Injection Control Driver (Bank 2)
D 54 Air Injection Control Driver (Bank 2)
D 58 Air Switching Valve (Bank 1)
D 59 Air Switching Valve (Bank 2)
D 60 A/C Compressor
D 62 ACIS VSV
D 63 Automatic Transmission
D 64 Automatic Transmission
D 65 Transmission Revolution Sensor (Turbine)
D 66 Transmission Revolution Sensor (Electronically Controlled Transmission)
D 67 Transfer Assembly
D 68 Transfer Assembly
D 70 Transfer Assembly
D 71 Junction Connector
D 72 Junction Connector
D 73 Junction Connector
D 74 Engine Control Module
D 75 Camshaft Timing Oil Control Valve (Bank 1 Intake side)
D 76 Camshaft Timing Oil Control Valve (Bank 2 Intake Side)
D 89 Air Pump (Bank 1)
D 90 Air Pump (Bank 2)


D 46
Gray




D 48
Black




D 50
Black




D 52
Gray




D 54
Gray



D 58
Black




D 59
Black




D 60
Gray




D 62
Black




D 63
Gray




D 64
Gray



D 65
Black




D 66
Black




D 67
Dark Gray




D 68
Gray




D 70
Black




D 71
White




D 72
White



D 73
Blue



D 74
Black




D 75
Black



D 76
Black



D 89
Black



D 90
Black

