

* 5:3UR-FBE
* 6:Except 3UR-FBE
W5
W1
W3
W7
W6
W4
Q3
Q5
Q2
Q10
Q7
Q6
Q4
X1
R14
R16
R4
R17
S4
S6
S3
R9
R6
(*6)
R19
(*5)
R12
R7
R8
R11
b4
R13
R15
R5
S5
S1
S8
S2
R18
b3
S7

Q 2 Front Pretensioner RH
Q 3 Curtain Shield Airbag Squib Circuit RH
Q 4 Side Airbag Sensor RH
Q 5 Front Door Courtesy Switch RH
Q 6 Rear Door Courtesy Switch RH
Q 7 Door Control Receiver
Q 10 Back Window Regulator Motor

R 4 Rear Combination Light Assembly RH
R 5 Rear Combination Light Assembly LH
R 6 Fuel Sender Gauge
R 7 Fuel Pump Control ECU
R 8 Fuel Pump Control ECU
R 9 Fuel Tank Solenoid Valve Assembly
R 11 Fuel Pump Control ECU
R 12 Canister Pump Module
R 13 Rear Combination Light Assembly LH
R 14 Rear Combination Light Assembly RH
R 15 Rear Combination Light Assembly LH
R 16 Rear Combination Light Assembly RH
R 17 Junction Connector
R 18 Trailer Socket
R 19 Fuel Sender Gauge


S 1 No.1 Ultrasonic Sensor (Rear Left)
S 2 No.1 Ultrasonic Sensor (Rear Left Center)
S 3 No.1 Ultrasonic Sensor (Rear Right Center)
S 4 No.1 Ultrasonic Sensor (Rear Right)
S 5 Blind Spot Monitor Sensor LH
S 6 Blind Spot Monitor Sensor RH
S 7 License Plate Light RH
S 8 License Plate Light LH

W 1 Inner Mirror
W 3 Sliding Roof Control ECU
W 4 Vanity Light RH
W 5 Vanity Light LH
W 6 Room Lamp
W 7 Roof Console Box Assembly


X 1 Television Camera

b 3 Rear Speed Sensor RH
b 4 Rear Speed Sensor LH


Q 2
Yellow



Q 3
Black



Q 4
Yellow




Q 5
White




Q 6
White




Q 7
White




Q 10
Black



R 4
Gray




R 5
Gray




R 6
White



R 7
Black




R 8
Gray




R 9
Dark Gray



R 11
Black



R 12
Black




R 13
Gray




R 14
Gray




R 15
Gray




R 16
Gray



R 17
Gray




R 18
Black




R 19
White




S 1
Black




S 2
Black




S 3
Black




S 4
Black



S 5
Black



S 6
Black




S 7
Gray




S 8
Gray



W 1
Black



W 3
White




W 4
White




W 5
White




W 6
White




W 7
White



X 1
Gray



b 3
Black



b 4
Black

