

* 3:3UR-FBE
* 4:Except 3UR-FBE
W5
W1
W7
W4
Q14
Q3
Q5
Q7
Q2
X1
b3
R14
R16
R4
R17
S4
S6
R9
R6
(*4)
R19
(*3)
R12
R7
R8
R11
b4
R15
R13
R5
S5
S1
S8
S2
R18
S7
S3

Q 2 Front Pretensioner RH
Q 3 Curtain Shield Airbag Squib Circuit RH
Q 5 Front Door Courtesy Switch RH
Q 7 Door Control Receiver
Q 14 Side Airbag Sensor RH

R 4 Rear Combination Light Assembly RH
R 5 Rear Combination Light Assembly LH
R 6 Fuel Sender Gauge
R 7 Fuel Pump Control ECU
R 8 Fuel Pump Control ECU
R 9 Fuel Tank Solenoid Valve Assembly
R 11 Fuel Pump Control ECU
R 12 Canister Pump Module
R 13 Rear Combination Light Assembly LH
R 14 Rear Combination Light Assembly RH
R 15 Rear Combination Light Assembly LH
R 16 Rear Combination Light Assembly RH
R 17 Junction Connector
R 18 Trailer Socket
R 19 Fuel Sender Gauge


S 1 No.1 Ultrasonic Sensor (Rear Left)
S 2 No.1 Ultrasonic Sensor (Rear Left Center)
S 3 No.1 Ultrasonic Sensor (Rear Right Center)
S 4 No.1 Ultrasonic Sensor (Rear Right)
S 5 Blind Spot Monitor Sensor LH
S 6 Blind Spot Monitor Sensor RH
S 7 License Plate Light RH
S 8 License Plate Light LH

W 1 Inner Mirror
W 4 Vanity Light RH
W 5 Vanity Light LH
W 7 Roof Console Box Assembly


X 1 Television Camera

b 3 Rear Speed Sensor RH
b 4 Rear Speed Sensor LH

Q 2
Yellow




Q 3
Black




Q 5
White




Q 7
White




Q 14
Yellow



R 4
Gray




R 5
Gray




R 6
White



R 7
Black




R 8
Gray




R 9
Dark Gray



R 11
Black



R 12
Black




R 13
Gray




R 14
Gray




R 15
Gray




R 16
Gray



R 17
Gray




R 18
Black




R 19
White




S 1
Black




S 2
Black




S 3
Black




S 4
Black



S 5
Black



S 6
Black




S 7
Gray



S 8
Gray



W 1
Black




W 4
White




W 5
White




W 7
White



X 1
Gray



b 3
Black



b 4
Black

