



J9
J25
J6
J26
J22
J19
J32
J28
J8
J4
J3
J29
J2
J1
J17
J35
J30
J31
J41
J10
J20
J11
J45
J13
J43
J12
J18
J42

J 1 Main Body ECU
J 2 Main Body ECU
J 3 Main Body ECU
J 4 Main Body ECU
J 6 Steering Angle Sensor
J 8 Power Window Regulator Switch (for Back Window)
J 9 Ignition Switch
J 10 Headlight Dimmer Switch Assembly
J 11 Spiral Cable
J 12 Windshield Wiper Switch
J 13 Windshield Wiper Switch
J 17 DLC3
J 18 Unlock Warning Switch
J 19 A/C Amplifier
J 20 Transponder Key Amplifier
J 22 VSC OFF Switch
J 25 Transmission Control Switch
J 26 Transponder Key ECU
J 28 Combination Meter
J 29 Flasher Relay
J 30 Shift Lock Control ECU
J 31 Tire Pressure Warning ECU
J 32 Blower Motor
J 35 Clearance Sonar ECU
J 41 No.1 Power Outlet Socket Assembly RH
J 42 No.1 Power Outlet Socket Assembly LH
J 43 Tire Pressure Warning Reset Switch
J 45 Spiral Cable


J 1
White




J 2
White




J 3
White




J 4
White




J 6
Gray




J 8
White




J 9
White




J 10
White




J 11
Yellow




J 12
White




J 13
White




J 17
White




J 18
White




J 19
White




J 20
Black




J 22
Black




J 25
White




J 26
White




J 28
Black




J 29
White




J 30
White




J 31
White



J 32
Black



J 35
Black




J 41
White



J 42
White



J 43
Black



J 45
Black

