



J62
J68
J61
J54
J70
J71
J73
J72
J67
J75
J60
J64
J53
J57
J50
J51
J66
J69
J52
J77
J74
J59
J65
J58
J46

J 46 Center Airbag ECU
J 50 Cargo Light Switch
J 51 Foot Light
J 52 Back-Up Light Relay
J 53 ACC Cut Relay
J 54 Diode (Ignition)
J 57 Glass Breakage Sensor ECU
J 58 Glass Breakage Sensor Microphone
J 59 Bus Buffer
J 60 Junction Connector
J 61 Junction Connector
J 62 Junction Connector
J 64 Junction Connector
J 65 Junction Connector
J 66 Junction Connector
J 67 Junction Connector
J 68 Junction Connector
J 69 Junction Connector
J 70 Junction Connector
J 71 Junction Connector
J 72 Junction Connector
J 73 Junction Connector
J 74 Junction Connector
J 75 Junction Connector
J 77 Junction Terminal


J 46
Yellow




J 50
Black




J 51
Black




J 52
White




J 53
Gray




J 54
Orange




J 57
White




J 58
White




J 59
White




J 60
White




J 61
Gray




J 62
Gray




J 64
White




J 65
White




J 66
Black




J 67
Blue




J 68
Gray




J 69
Gray




J 70
Blue




J 71
White




J 72
Black




J 73
Black



J 74
Gray



J 75
Gray



J 77
White

