

(*1)
(*2)
(*1)
(*2)
(*1)
(*2)
z5
z4
z3
z2
K2
K1
K5
K3
K6
L1
L2
I3
I2
I1
* 1:w/ Navigation System
* 2:w/o Navigation System
A53
A50
A5
A4
A14
A25
A26
A51
A52
A35
K4
L3
P1
Q1
z1

A 4 Stop Light Switch
A 5 Parking Brake Switch
A 14 Accelerator Position Sensor
A 25 4WD Control ECU
A 26 4WD Control ECU
A 35 Diode (Starting)
A 50 Junction Connector
A 51 Junction Connector
A 52 Junction Connector
A 53 Diode (Magnet Clutch Relay)

I 1 Front Passenger Side Squib Circuit
I 2 Front Passenger Side Squib Circuit
I 3 Front Passenger Side Squib Circuit

K 1 Navigation Receiver Assembly
K 2 Stereo Component Tuner Assembly
K 3 Navigation Receiver Assembly
K 4 Stereo Component Tuner Assembly
K 5 Radio & Display Receiver Assembly
K 6 Radio & Display Receiver Assembly


L 1 Navigation Receiver Assembly
L 2 Radio & Display Receiver Assembly
L 3 Stereo Component Tuner Assembly

P 1 Center Airbag ECU

Q 1 Center Airbag ECU

z 1 A/C Amplifier , A/C Blower Assembly
z 2 Spiral Cable , Cruise Control Main Switch
z 3 Spiral Cable , Steering Pad Switch
z 4 Spiral Cable , Driver Side Squib Circuit
z 5 Spiral Cable , Driver Side Squib 2nd Step Circuit


A 4
White




A 5
White




A 14
Black



A 25
Black




A 26
White




A 35
Black




A 50
White



A 51
Black




A 52
White




A 53
White




I 1
Black




I 2
Orange




I 3
Orange




K 1
Brown




K 2
Brown




K 3
White




K 4
White




K 5
Brown




K 6
White




L 1
White




L 2
White




L 3
White




P 1
Yellow




Q 1
Yellow




z 1
White




z 2
White



z 3
White



z 4
Orange



z 5
Black

