


z5
z4
z3
z2
K2
(*3)
K1
(*4)
K5
(*3)
K3
(*4)
K6
(*3)
L1
(*4)
L2
I3
I2
I1
* 3:w/ Navigation System
* 4:w/o Navigation System
A53
A50
A5
A4
A14
A25
A26
A51
A52
A35
K4
L3
P1
Q1
z1
T2
T3

A	4	Stop Light Switch
A	5	Parking Brake Switch
A	14	Accelerator Position Sensor
A	25	4WD Control ECU
A	26	4WD Control ECU
A	35	Diode (Starting)
A	50	Junction Connector
A	51	Junction Connector
A	52	Junction Connector
A	53	Diode (Magnet Clutch Relay)
I	1	Front Passenger Side Squib Circuit
I	2	Front Passenger Side Squib Circuit
I	3	Front Passenger Side Squib Circuit
K	1	Navigation Receiver Assembly
K	2	Stereo Component Tuner Assembly
K	3	Navigation Receiver Assembly
K	4	Stereo Component Tuner Assembly
K	5	Radio & Display Receiver Assembly
K	6	Radio & Display Receiver Assembly
L	1	Navigation Receiver Assembly
L	2	Radio & Display Receiver Assembly
L	3	Stereo Component Tuner Assembly
P	1	Center Airbag ECU
Q	1	Center Airbag ECU
T	2	No.2 Power Outlet Socket Assembly
T	3	Rear No.1 Power Outlet Socket Assembly
z	1	A/C Amplifier , A/C Blower Assembly
z	2	Spiral Cable , Cruise Control Main Switch
z	3	Spiral Cable , Steering Pad Switch
z	4	Spiral Cable , Driver Side Squib Circuit
z	5	Spiral Cable , Driver Side Squib 2nd Step Circuit


A 4
White




A 5
White




A 14
Black



A 25
Black




A 26
White




A 35
Black




A 50
White



A 51
Black




A 52
White




A 53
White




I 1
Black




I 2
Orange




I 3
Orange




K 1
Brown




K 2
Brown




K 3
White




K 4
White




K 5
Brown




K 6
White




L 1
White




L 2
White




L 3
White




P 1
Yellow




Q 1
Yellow




T 2
White




T 3
White




z 1
White




z 2
White



z 3
White



z 4
Orange



z 5
Black

